

Speciality Tips

Wide bore tips reduce damaging shear forces when handling genomic DNA, labile cells and organelles.

2180 Series 200µl Wide Bore Tip

code	packaging	tip type	units/pack	packs/case
2180	Bulk	Natural PP	1000/bag	10
2182	Racked	Natural PP	10 trays of 96	5
2182.S	Racked/Pre-sterilized	Natural PP	10 trays of 96	5



2190 Series 1000µl Wide Bore Tip

code	packaging	tip type	units/pack	packs/case
2190	Bulk	Natural PP	1000/bag	10
2192	Racked	Natural PP	10 trays of 96	–
2192.S	Racked/Pre-sterilized	Natural PP	10 trays of 96	–



Extra Long Tips

Tips easily reach the bottom of test tubes or culture flasks. At 100mm in length, this tip offers that little extra reach you need.

2150 Series 200µl Extra Long Tip

code	packaging	tip type	units/pack	packs/case
2150	Bulk	Natural PP	1000/bag	5
2152	Racked	Natural PP	8 trays of 204	3



Picture is 70% of actual size.